

Installation Guide for SMG Paddles

Tools required: Torx T-20

Time required: +/- 5 minutes



1.) Original OEM Paddles



2.) Look behind the steering wheel, you will find the screw that holds the paddles to the steering wheel. Use Torx T-20 to take the screw out



3.) You will see a spring sticking out from the steering wheel.



4.) Put Paddles on proper position and put the screw back in using Torx T-20

5.) Repeat for the left side. You are done!
