

Thank you for purchasing Bimmian.com Colored M Stripe Overlays

Pre-installation Preparation:

-Before installing Colored M Stripe Overlays please clean installation area free from oil and dirt.

-Please do not apply overlays in direct sunlight as the vehicle will be hot and this may stretch the overlay. Install in a cool, shady area if possible.

Pre-installation Note:

-Our M stripes are designed to be put on in groups of 3 colored stripes, they are not designed to be put over just one or two stripes. In most cases your original stripes are not equally sized in width. Our M stripes are designed by taking the width of the entire M color sticker on your emblem and then divided by 3. For this reason if you apply just one or two colors they may not fully cover the color you are overlaying.

-When aligning overlays during application please note that on your OEM M Emblems some M stripes are sticker, some are plastic color inserts and others are beveled metal. In most cases our stripes are designed to match the size of the cavity where the OEM sticker is applied, and not matched to the size of the sticker itself.

-M stripe overlays may be applied with water to allow easier alignment, and then dried with a hair dryer and towel.

Installation:

-Begin by finding the correct stripe size on the sheets of stripes by referencing the chart below.

-Choose the order of the colors you will be applying from right to left.

-Install the first stripe by removing it from the sheet with the edge of a knife and applying it by aligning the top right corner.

-Once you are happy with the alignment press down making sure the stripe is aligned along the right side. If it is not correctly aligned, lift the stripe gently and reapply. This may cause the stripe to stretch a bit. Don't worry about any excess material you end up with at the bottom just yet.

-Apply the rest of the stripes using the same method described above. Do your best to but them up against each other. If you overlap the stripes you may end up with some of the original stripes exposed.

-Once all 3 stripes are applied you can run a sharp exacto blade along the bottom of the emblem ridge (right to left) to cut of any excess material that may have stretched over.



STRIPE NUMBER AND VEHICLE FITMENT:

- 1) E60 M5 (Rear)
- 2) E70 X5M (Engine) E71 X6M (Engine) E60 M5 (Engine) E63 M6 (Engine) E46 M3 (Engine)
- 3) E85/E86 Z4M (Rear)
- 4) E70 X5M (Rear) E71 X6M (Rear)
- 5) E46 M3 (Rear)
- 6) E90/E92/E91/E93 M3 (Rear)
- 7) E90/E92/E91/E93 M3 (Engine)
- 8) E85/E86 Z4M (Side) x2
- 9) F10 M5 (rear) F12/F13 M6 (rear)
- 10) F10 M5 (engine) F12/F13 M6 (engine)
- 11) E63 M6 (Rear) E82 1M (Rear)
- 12) F12/F13 M6 (Front Grille)