



# CF SHIFT KNOB INSTALLATION INSTRUCTIONS

- 1) Remove the OEM shifter knob by gripping it tightly and pulling up with force. Be careful not to be in the path of the shifter knob when pulling up.



- 2) Replace OEM shift knob with Carbon Fiber shift knob. Push down firmly on the shift knob to lock it in place.