

FOG LIGHT MOLDING

ABS EDITION INSTALLATION GUIDE



TOOL REQUIRED FOR INSTALLATION:

No tools are required for installation.

- 1) Place your thumb on the front of the fog ring. Use your fingers to reach into the bumper and grab hold of the rear of the fog ring.



- 2) Pull out towards you and remove. Clean area.

- 3) Insert fog light molding with the tab on an angle (as show), then rotate to align with vent.



- 4) The white arrow shows the area that needs to grip to the inside of the vent hole. Flex fog molding to help this area grab onto the vent hole unobstructed.

- 5) Feel behind the vent hole to make sure the fog light has attached securely. Be careful when installing not to scratch your vent area.



- 6) Once you feel the fog light molding is securely, adjust alignment to bumper by pulling up or down on vent hole.

*Molding can be removed by flexing in the centre, outward, to help clip release.