

MOUNTING LOCATION:

Right side of cassette player door

TOOLS REQUIRED:

Phillips screwdriver
Flat screwdriver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75103-397**
MFG: **BMW**
MODELS & YEARS:
528I 96-2000
525I 2001-03, 530I 2001-03
540I 1996-03, M5 2001-03

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDashMounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1 With the flat screwdriver remove the wooden trim located between the air bag and glove compartment. Carefully insert the screwdriver between the trim and the dash, at about the center of the trim, prying evenly to release. Once trim is released, set aside.
- STEP #2 Under the wooden trim that you just removed, you will find four (4) screws, remove the first screw on the left side.
- STEP #3 Attach the phone holder to InDash Mount. If using a PortaGrip #701, adjust to size of the phone prior to mounting. Place InDash over the screw hole and install the screw.
- STEP #4 Place the wooden trim back to original position and push in to lock into place.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Finished Install Picture



01-17-03