

MOUNTING LOCATION:

Right side of cubby box MR

TOOLS REQUIRED:

Phillips head screwdriver

Flat Style Hook/Pry Tool

HARDWARE INCLUDED:

(2) O - 8-32 Acorn Nut

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75103-304**

MFG: **BMW**

MODELS & YEARS: **525i 2004**

530i 2004

545i 2004

(AT-only)

STEP #1: Begin by removing the bezel that includes the (2) center air vents and passenger side air vent. Open the passenger door. Insert the flat hook/pry tool into the side of the bezel to the right of the passenger air vent, pull to release (1) clip. Pull out on the bezel with your hands to release (3) more clips. To assist with the release of these clips tilt the bezel up and down slightly. Continue to release the final clip to the left of the center air vents. You do not need to remove this bezel completely.

STEP #2: Lift up on the bezel to expose (2) Phillips screws. These screws are located above the climate control to the right and left sides. Remove these screws and set them aside. Tilt out the climate control to begin to release the bezels that surround and includes the climate control, the bezel surrounding the CD slot and sound button, also the cubby box and DSC button. There are (2) clips located to the lower right and left of the climate control bezel.

STEP #3: You need to pull out the climate control and cubby bezels together as they are connected. Tilt the climate control out enough to get at the clip with hook tool to release (1) side. Then use your hands or hook tool to release the clip located below the cubby box 1" in from the right. With your hands slightly tilt out the climate control, grasp the bottom of the cubby box bezel, and inside right side of cubby box, pull to release the (1) clip between the climate control and the cubby box bezel. Repeat on the left side of these bezels also.

STEP #4: With emergency brake engaged, shift transmission into D. Pull out bezel enough to get at the Phillips screw located in the lower right corner of cavity. Remove this screw and install the part #8A with the studs facing up. Reinstall bezels in reverse order. Install the InDash by PanaVise Mount part with the part number onto the 8A part with the (2) supplied nuts.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

**** ADVISEMENT ****
Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Screw locations



Clip at climate control and cubby box



Part 8A installed on mounting screw



Prototype InDash installed showing mounting placement



All pictures are of prototypes



06-29-04