

### MOUNTING LOCATION:

Right side of air vents

### CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

### TOOLS REQUIRED:

#2 Phillips screwdriver  
Flat head screwdriver  
3/32" drill bit and drill

PART#: **75103-401**  
MFG: **BMW**  
MODELS & YEARS:  
**Z3 Roadster 97-2002**

### HARDWARE INCLUDED:

(3) needle point screws [3A]

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1** Begin by removing the air vents that are above the radio. Use caution, as the clips are fragile. To do this, carefully insert the flat head screwdriver between the top of vents and the dash. It may be necessary to pry out the vents from the bottom, between the vents and the radio. Be sure to protect the wood trim with cardboard or shop towel. Once the clips are loose, grasp the vents and pull out of its cavity. Set the bezel aside.

**STEP #2** Inside and to the right of the air vent cavity, locate the flat spot where the InDash by PanaVise will go. Place the InDash by PanaVise over this flat spot. Adjust the angle of the phone, then use your marking pen and the holes in the InDash by PanaVise as a guide to mark two spots for drilling pilot holes. Set the InDash by PanaVise aside. Depending on the angle of the InDash when it is mounted. *Be aware of possible glare on NAV or Phone screen in the convertible.*

**STEP #3** Using your 3/32" drill bit and drill, carefully drill two pilot holes. Place the InDash by PanaVise over the pilot holes. Insert the (3) provided screws and tighten with your Phillips screwdriver.

**STEP #4** Replace the air duct module securing all four plastic clips.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Placement of InDash Mount



Finished Install Picture



03-08-02